

User Guide

Ethernet Expansion Card

USRobotics®

A Division of UNICOM® Global

www.usr.com

Copyright

© 2014 USRobotics. All rights reserved.

Trademarks

USRobotics[®], Courier[™] and the USRobotics logo are registered trademarks of U.S. Robotics Corporation.

Sierra Wireless[®], AirPrime[®], AirLink[®], AirVantage[®] and the Sierra Wireless logo are registered trademarks of Sierra Wireless.

Contact Information

Web:	http://www.usr.com/contact
------	---

Consult our website for up-to-date product descriptions, documentation, application notes, firmware upgrades, and troubleshooting tips: <http://www.usr.com/support/3500>

Document History

Version	Date	Updates
001	Jan, 14 2014	Creation

Contents

1. OVERVIEW	6
1.1. Parts and Interfaces.....	6
1.2. External Connection	7
2. FEATURES AND SERVICES	8
3. USING THE ETHERNET EXPANSION CARD.....	9
3.1. Installation.....	9
3.2. Enable the expansion card	10
3.3. Operational Status.....	10
4. TROUBLESHOOTING	11
4.1. No Communications	11
5. APPENDIX A: PACKAGING.....	12
5.1. Contents	12
5.2. Production Stickers.....	13

List of Figures

Figure 1.	Expansion card – Top Side	6
Figure 2.	Expansion card – Bottom Side	7
Figure 3.	10-pin Interface Socket.....	7

List of Tables

Table 1.	Basic Features	8
Table 2.	Operational Status	10
Table 3.	No Link or Activity Status	11

1. Overview

The Ethernet expansion card broadens the functionality of a standard USR3500 Cellular Modem to now include Ethernet machine to machine applications, allowing a wider reach into potential applications and solutions.

1.1. Parts and Interfaces

The following figure shows the top and bottom views of the expansion card, and identifies its different parts and connectors.




Figure 1. Expansion card – Top Side




Figure 2. Expansion card – Bottom Side

1.2. External Connection

The expansion card has a 10-pin socket, which is used as the external interface for the RJ-45 Ethernet cable.




Figure 3. 10-pin Interface Socket

2. Features and Services

This section enumerates the features and services available on the Ethernet expansion card.

Table 1. Basic Features

Features	Description
LAN	<ul style="list-style-type: none">• IEEE 802.3 Compatible• Integrated MAC and 10 BASE-T PHY• Receiver and collision squelch circuit• Supports one 10BASE-T port• Supports Full and Half-Duplex modes• Shielded RJ-45

3. Using the Ethernet Expansion Card

3.1. Installation


To install the expansion card, follow the procedures listed below.

Caution: Remove the power from the USR3500 when installing the expansion card.

1. Unscrew the original backplate.



2. Align the expansion card on the guide rail inside the USR3500. Slide the board until the 50-pin connector mates with the USR3500.



3. Replace the original backplate with the new expansion backplate and screw it in place.



4. Connect the interface cable to the expansion card.

3.2. Enable the expansion card

To enable the expansion card, perform the following steps.

1. Connect a serial cable between the USR3500 and the PC COM port.
2. Connect the RJ45 Ethernet cable between the expansion card and an Ethernet network with a DHCP server.
3. Apply power to the USR3500.
4. Open a communication software (for example, HyperTerminal); if the COM port isn't configured yet, configure it as follows:
 - Bits per second: 115200
 - Data bits: 8
 - Parity: None
 - Stop bits: 1
 - Flow control: None
5. Ensure the Courier M2M application is active by entering the command `AT+WOPEN=1` to start the application
6. Enter the command, `AT$ENABLEETHERNET=1`
7. Enter the command `AT+CFUN=1` to restart the USR3500.
8. Refer to the USR3500 Application Guide for further configuration details.

3.3. Operational Status

The operational status is indicated by the green and yellow LEDs located at the front end of the expansion card.

The following table describes the operational status.

Table 2. Operational Status

LED Description	LED Status	Status
Link LED (Green)	ON	The Ethernet is in sync with the LAN/router.
	OFF	The Ethernet is not in sync with the LAN/router; or the Courier M2M application is not running.
Activity LED (Yellow)	ON – Blinking	The Ethernet is linked to the network.
	OFF	The Ethernet is not in sync with the LAN/router; or the Courier M2M application is not running.

4. Troubleshooting

This section describes the possible problems that might be encountered when using the expansion card and their corresponding solutions.

4.1. No Communications

If the expansion card does not enable or communicate its status, refer to the table below for possible causes and their corresponding solutions.

Table 3. No Link or Activity Status




Ask	Action
Is the USR3500 powered correctly?	Make sure that the external power supply is connected to the USR3500 and provides a voltage within the range of 4.75V to 32V.
Is the expansion card powered properly?	Make sure that the expansion card is properly plugged in to the USR3500.
Is the RJ45 Ethernet cable properly connected at both sides?	Check the RJ45 Ethernet cable connection.
Is the expansion card properly enabled?	Use the the command <code>AT\$ENABLEETHERNET?</code> to verify. Refer to the USR3500 Application Guide for further details.

5. Appendix A: Packaging

5.1. Contents

The Ethernet expansion card package contains the following:

- Expansion Card
- Backplate and Spring Contacts
- RJ45 Interface Cable

	
Expansion Card	Backplate and Spring Contacts
	
RJ45 Interface Cable	

5.2. Production Stickers

Production and MAC address stickers are located at the back of the expansion card, and contains the following information:

- Product Name (IESM Ethernet)
- AirLink logo
- Marketing Name (FXTE02)
- Barcode
- 17-digit Serial Number
- MAC Address